

storeWALL GO-Bracket instructions

(using freedomRail® GO-Boxes, Cabinets, Lockers)

1. Insert storeWALL GO-Brackets into storeWALL panel at desired height and location.
 - a. Hang assembled GO Unit over brackets. Attach to mounting bracket holes using Euro screws provided with cabinet.
 - b. Repeat above procedure for second side panel of each Schulte GO unit.

- OR -

2. Pre-attach GO-Brackets onto both sides of GO Units using the bracket holes and Euro screws provided with cabinet. Hang GO Units onto panels.

3. When using more than one Schulte GO unit in a stack:
 - a. Install lowest (bottom) Schulte GO unit first.
 - b. Assemble second GO unit (without middle shelves and doors) and place on top of bottom GO unit.
 - c. Attach set of storeWALL GO-Brackets to each stacked Schulte GO unit:
 - i. Insert GO-Bracket into storeWALL near top of GO unit.
 - ii. Slide GO-Bracket against side panel of GO Unit.
 - iii. Using a 5mm bit, carefully drill pilot-holes through all holes in each storeWALL GO-Bracket. (DO NOT DRILL TOO DEEP TO DRILL THROUGH SIDE PANELS - PLEASE BE CAREFUL)
 - iv. Attach GO-Brackets to left & right side panels using euro-screws provided with cabinet.

4. Plumb cabinets and insert GO-Stops (if provided) inside cabinet near bottom. (optional item)
5. Install doors and additional shelves (if desired).



1



2



3a

NOTE:
To prevent drilling through side panels, use tape on drill bit to mark depth of pilot-holes to be drilled.



3b



3c



4



5