

PTH-reversible hook



Location of C-ring
Pop-off with flat screw driver.
To replace, use pliers.



C-ring clip
Holds arm in place.

The PTH hook can be adjusted for right and left hand use. In addition it can be used as a pair for more organization and storage functions.

The PTH hook is right hand when shipped.



PTH
Right hand setting.



PTH
Left hand setting

Right hand, left hand and combination use

